

TIPS FOR SEWING POLYFAB SHADE SAIL EDGE WEBBING

Cable Edge Shade Sails: Cable edged sails are sewn with reinforcements on the top of the sail. Fold over ½” and sew around the perimeter capturing corner reinforcements at each corner. Then fold over 2” to make the pocket and sew around the perimeter. Don’t sew across the pocket—it must be free of obstructions for the cable to be installed.



Alternate Corner Technique:



Webbing Edge Shade Sails: Webbing edged sails are sewn with the webbing on the underside of the sail. Fold over ½” and sew under webbing. Sew 2nd stitch keeping the bulk of the fabric loose. When stitching across the webbing at the corners, don’t sew across more than 3 times or you risk perforating the webbing.

